



114

11

114

11

853



109

113

114

11

A diagram of a horizontal beam with a downward-pointing arrow above its center, representing a point load.



90°

© 2022 Fir Italia S.p.A. www.fir-italia.it info@fir-italia.it